

93004300

sklen.6ks 170ml MISKET
v13,2cm - bílé víno



93004330

sklen.6ks 365ml MISKET
v17,7cm - r zné užití



93010420

miska 6ks 250ml MASTER
kompot, sklo



91901090

box 1,35I FRESH
d lený(3x0,45I),d21x6cm,tr
ansp.plast



91900500

mísa 27,5x5,5cm trojboká,
d lená s víkem,plast



91901500

podnos 36x27cm,obdél.
MIX barev, protiskluz.,plast




10804730

odm rka 1l PP mouka,
cukr, mlé ná,plast



86423730

box 14I úložný
38,6x29,4x18cm,vložky,pla
st



31230010

zapalova plnicí zasouvací
GH-11



95090110

hodiny tverc.21x21cm,bílý
rám



95090120

hodiny
tverc.21x21cm, erný rám



20700030

návnada na hubení
mravenc 120gr



86618510

blok na nože
plátky(voština) d11x22
plast



86422870

box 44I 597x394x312mm



11802922

kelímek 0,2l "POTISK"
plast



37503710

stojan na pe ení ku ete
NR+mašlova ka



86677110

hrnek 275ml kónický, bílý
porcelán



22723010

tvo ítko na 4ks nanuk UH



13041531

prachovka DUSTER XL
Color "LFH"



13041669

st rka 30cm na sprch.kout



13055020

mop PROFI
42cm, MICRO+AL h I



21293040

držák truhl.
FIXPOT-teracota (1pár),kov



21293042

držák truhl.
FIXPOT-antracit (1pár),kov



21293044

držák truhl.
FIXPOT- okoláda
(1pár),kov



21293050

adaptér drž.truhl.
FIXPOT-hn dá(1pár),kov



21293052

adaptér
drž.truhl.FIXPOT-bílá(1pár),
kov



70820150

návlek na smeták Mop
ULTRA



22726030

ajník 1,3l NR DIANA bez
ví ka



31211700

ut rky
kuch.2vr.,55m,300úst iž.,X
XL WAY,extra savé



31210520

taška 3kg/100ks,mikroten
38x21cm



31210530

taška 4kg/50ks,mikroten
47x23cm,extra, GRAN.



31210540

taška
4kg/100ks,mikrot.51x30cm,
pruhy

